

Adhesive Backed Vinyl Application – Glass or Car Body

- Please read instructions first
- You will need:
 - Windex or similar product
 - Credit card or squeegee (under \$1.00 purchased at auto supply store)
- Clean surface with Windex to remove dust, oil, etc
- Place decal in exact position and location. *Without* removing paper backing, apply masking tape along an edge – usually the top.
- Review placement – it cannot be repositioned.
- Fold the decal back along the tape hinge.
- Remove the backing to reveal the sticky side. **Do not allow decal to fall on to the surface.**
- Hold the decal away from the surface with one hand and with squeegee / credit card, carefully begin smoothing down 1-2 inches along the hinged edge. **DO NOT SMOOTH DOWN WITH YOUR HANDS FIRST**
- Work across the graphic from the hinge out, overlapping your strokes. Try not to trap any air bubbles behind the vinyl.
- **Re-squeegee the entire area to ensure bond.**
- Remove the transfer tape by starting at a corner and pulling towards the opposite corner away from the surface at a 180 degree angle.
- Re-squeegee if there are any loose areas as you remove tape.
- Bubbles:
 - Small bubbles will disappear over time and with temp changes.
 - If large air bubbles appear, puncture with a pin and rub the area to flatten the bubbles.

Removal

To remove the applied vinyl, heat area with a heat gun/hot hair dryer and gently pull vinyl away. On glass surfaces, a razor blade may be used for easy removal.

Standard Disclaimer: Properly cured surfaces should not be damaged by vinyl application or removal but neither we nor the manufacturer can be responsible for any damages.